



STEP 3

Attach **(E)** into counter sunk holes of **Headboards (L/R)**. Go on to complete the **Assembly**.

ASSEMBLY INSTRUCTION

MODEL : WS 1602 HAMPTON DAY BED (915 x 1905)MM











STEP 2


Attach **Wooden Slats** onto **Back Rest** and **Side Rail** by using **(D)**, tighten it up by using a Crosshead Screw Driver.

HARDWARE LIST


<p>A</p>  <p>PLASTIC DOWEL (M10 x 35MM)</p>	<p>B</p>  <p>JCBC BOLT (M6 x 90MM)</p>	<p>C</p>  <p>JRN NUT (M6 x 13MM)</p>
<p>D</p>  <p>CSK C/B SCREW (M4 x 32MM)</p>	<p>E</p>  <p>PLASTIC CAP (M15)</p>	<p>F</p>  <p>ALLEN KEY (M4 x 60MM)</p>

Tools Required :
 Crosshead Screw Driver
 Rubber Hammer


PARTS LIST




HEADBOARD (L/R)
(2 PCS / SET)
CARTON 1 OF 3




BACK REST
(1 PC / SET)
CARTON 2 OF 3



SIDE RAIL
(1 PC / SET)
CARTON 2 OF 3



WOODEN SLATS
(12 PCS / SET)
CARTON 3 OF 3



STEP 1

Insert **(A)** into $\varnothing 10$ holes on **Back Rest** and **Side Rail** by using a Rubber Hammer.

Attach and secure **Back Rest** and **Side Rail** onto both **Headboards (L/R)** by using **(B)** and **(C)**, tighten it up by using **(F)**.